

Electrolyte for Aluminum Plating Based on 1-Ethyl-3-methylimidazolium

tetrachloroaluminate 1:1.5

Revision Date:	10/20/2016
Date Issued:	7/22/2017

1 IDENTIFICATION OF THE SUBSTANCE/PREPARATION AND THE COMPANY/UNDERTAKING

Product name	1-Ethyl-3-methylimidazolium tetrachloroaluminate 1:1.5
Product code	EP-0001
CAS	not available
Supplier	loLiTec Ionic Liquids Technologies GmbH Salzstrasse 184 D – 74076 Heilbronn Germany
Telephone	+49 (0)7131-89839-0
Fax	+49 (0)7131-89839-109
Emergency telephone	+49 (0)179-5322578
Email	info@iolitec.de

2 COMPOSITION/INFORMATION ON INGREDIENTS

Ingredient name	1-Ethyl-3-methylimidazolium
	tetrachloroaluminate, aluminum chloride
CAS No.	not available
Empirical Formula	not available
Structure	not available
Molecular weight	not available
Purity	>98%



Electrolyte for Aluminum Plating Based on 1-Ethyl-3-methylimidazolium

tetrachloroaluminate 1:1.5

Revision Date:	10/20/2016
Date Issued:	7/22/2017

3 PROPERTIES

Color	yellowish
Physical state (25 °C)	liquid
Melting point	<10 °C
Glass transition temperature	not available
Decomposition temperature	not available
Density (25 °C)	not available
Viscosity (25 °C)	not available
Heat capacity (25 °C)	not available
Conductivity (20 °C)	not available
Electrochemical stability window	not available
Anodic limit	not available
Cathodic limit	not available

4 CO-SOLVENT MISCIBILITY

Water	reacts violently with water forming HCI Gas
Acetone	miscible
Acetonitrile	not available
Isopropanol	not available
Toluene	not available
Hexane	not available



Electrolyte for Aluminum Plating Based on 1-Ethyl-3-methylimidazolium

tetrachloroaluminate 1:1.5

 Revision Date:
 10/20/2016

 Date Issued:
 7/22/2017

5 APPLICATION GUIDELINES

This electrolyte should be stored and handled under dry, inert gas like argon or nitrogen. After filling the electrolyte into the plating bowl it should be mixed for at least 15 min. The material of the plating bowl should be glass or teflon coated metal. For the plating process the cathode should be the working electode with the sample that should be coated and the anode should be out of aluminum (99.99+%). The anode to cathode ratio should be approximately 1:1. To receive an optimal performance of the electrolyte, the electrode materials should be cleaned prior to use. Therefore we suggest to sonicate the plates for 20 min with hexane and for another 20 min with acetone. After that the aluminum plate should be dipped in a mixture of 30% phosphoric acid, 30% sulfuric acid and 40% nitric acid. The further cleaning process of the workpart depends on its material. We suggest to clean copper or steel with a solution of 10 M hydrochloric acid. The electrode materials should be cleaned first with water and then with acetone after the handling with acids. The last step of the cleaning procedure is drying of the electrode materials. The optimal distance between the electrodes is determined by the dimensions of the electrodes. For small plates of 10.7 cm² (complete surface including opposite of the counter electrode) the optimal distance is at 1.5 cm. We received the best plating results by using a current density of 6.3 mA/cm² at 30 °C with moderate stirring. For bigger workparts of 31 cm² an electrode distance of 3 cm and a current density of 11.3 mA/cm² is suggested. The deposition should be done under current control. With a sample program as follows:

Area: 10.7cm², distance electrodes 1.5 cm, Material Cu 0.05 A for 20s \rightarrow -0.065 A for 200s \rightarrow 0.05 A for 20s \rightarrow -0.065 A for 200s Repetition of this program depending on the requested layer thickness.

The optimal voltage for the deposition process lies between 0.8 and 1.2 V. If the voltage exceed those values the current must be reduced or the distance between the electrode must be reduced. Higher voltages of 3V or more will decompose the electrolyte and will result in black coatings. The cleaning of the workparts should be



Electrolyte for Aluminum Plating Based on 1-Ethyl-3-methylimidazolium

tetrachloroaluminate 1:1.5

Revision Date:	10/20/2016
Date Issued:	7/22/2017

performed by rinsing them with dry 1-ethyl-3-methylimidazolium dicyanamide (IL-0003-HP) or by rinsing it with aceton followed by stirring for 10 min with 3M[™] Novec[™] 7300 Engineered Fluid (FL-0003-HP). After that the workpart should be cleaned over a separate bowl with acetone. It is important that you do not add a big amount of acetone or water to the electrolyte because this will reduce the performance of the electrolyte.

6 ORDER INFORMATION

	3
Quantity	Price
25 g	Please enquire
50 g	Please enquire
100 g	Please enquire
250 g	Please enquire
500 g	Please enquire
1 kg	Please enquire
Bulk	Please enquire

EP-0003-HP can be obtained in the following standard quantities:

Please send your order via email to <u>order@iolitec.de</u> or fax +49 (0)7131 – 89839109.

6 OTHER INFORMATION

DISCLAIMER

THE ABOVE INFORMATION IS BELIEVED TO BE CORRECT BUT DOES NOT PURPOSED TO BE ALL INCLUSIVE AND SHALL BE USED ONLY AS A GUIDE. IOLITEC SHALL NOT BE HELD LIABLE FOR ANY DAMAGE RESULTING FROM HANDLING OR FROM CONTACT WITH THE ABOVE PRODUCT. THIS INFORMATION RELATES ONLY TO THE SPECIFIC MATERIAL DESIGNATED AND MAY NOT BE VALID FOR SUCH MATERIAL USED IN COMBINATION WITH ANY OTHER MATERIALS OR ANY PROCESS. IT IS THE USERE'S RESPONISIBILTY



Electrolyte for Aluminum Plating Based on 1-Ethyl-3-methylimidazolium

tetrachloroaluminate 1:1.5

Revision Date:	10/20/2016
Date Issued:	7/22/2017

TO SATISFY HIMSELF AS TO THE SUITABILITY OF SUCH INFORMATION FOR HIS OWN PARTICULAR USE.

IN NO WAY SHALL IOLITEC BE LIABLE FOR ANY CLAIMS, LOSSES OR DAMAGES OF ANY THIRD PARTY OR FOR THE LOST PROFITS OR ANY SPECIAL, INDIRECT, INCIDENTAL, CONSEQUENTIAL OR EXEMPLARY DAMAGES, HOWSOEVER ARISING, EVEN IF THE COMPANY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.